

Duration Home[®]

Interior Latex Flat

A95 Series



CHARACTERISTICS

Duration Home[®] Interior Latex with Moisture Resistant Technology™ offering quick return to service & durability in moist environments like bathrooms.

Also provides:

- Long lasting beauty
- Washability & Cleanability
- Resistant to stains, scuffs & burnishing
- Very easy application
- Anti-Microbial*

Color: Most Colors
To optimize hide and color development, always use the recommended P-Shade primer.

Coverage: 350-400 sq. ft. per gallon
@ 4 mils wet, 1.6 mils dry

Drying Time, @ 77°F, 50% RH:

Touch: 1 Hour
Recoat: 4 Hours

Drying and recoat times are temperature, humidity, and film thickness dependent.

Finish: 0-5 units @ 60°
1-5 units @ 85°

Tinting with CCE only:

Base: oz. per gallon: **Strength:**

Extra White	0-7	SherColor
Deep Base	4-12	SherColor
Ultradeep Base	10-12	SherColor
Accent Base	12-20	SherColor

Extra White A95W02351

(may vary by color)

V.O.C.(less exempt solvents):

less than 50 grams per litre; 0.42 lbs. per gallon
As per 40 CFR 59.406

Volume Solids: 40 ±2%

Weight Solids: 61 ±2%

Weight per Gallon: 12.07 lbs

Flash Point: N.A.

Vehicle Type: Styrene Acrylic

Shelf Life: 36 months, unopened

*Anti-microbial

This product contains agents which inhibit the growth of mold and mildew on the surface of this paint film.

COMPLIANCE

As of 11/10/2025, Complies with :

OTC	Yes
OTC Phase II	Yes
S.C.A.Q.M.D.	Yes
CARB	Yes
CARB SCM 2007	Yes
CARB SCM 2020	Yes
Canada	Yes
LEED [®] v4 & v4.1 Emissions	Yes
LEED [®] v4 & v4.1 V.O.C.	Yes
EPD-NSF [®] Certified	Yes
MIR-Manufacturer Inventory	Yes
MPI [®]	No

APPLICATION

Apply at temperatures above 50°F. No reduction needed.

Brush: Use a nylon-polyester brush such as Purdy[®] XL[®].

Roller: Use a high-quality polyester roller cover such as Purdy[®] Altitude™.

For best final appearance when rolling, finish off in one direction, especially for dark colors.

For specific brushes and rollers, please refer to our Brush and Roller Guide on the Sherwin-Williams web site.

Spray - Airless:
Pressure 2000 p.s.i.
Tip .015-.019 inch

APPLICATION TIPS

For touching-up, reduce the product by one pint per gallon.

To assure maximum washability and durability, wait at least 14 days before washing **Duration Home** coating.

When removing stains, dirt, and marks, use a soft cloth or sponge with water. Stubborn stains may require the use of a general-purpose household cleaner of total removal. Do not use an abrasive cleaner or scrub brush to remove stains.

Surfactant leaching is a term used when a concentration of water-soluble paint ingredients called "surfactants" are noticed on the surface of a latex paint film. Surfactant leaching is most seen as a streak or stain of tan, brown, or clear spots that sometimes can be glossy, soapy, oily or even sticky. Surfactants are soap-like materials that help in the dispersion of the paint's pigment and latex binders.

Duration Home with Moisture Resistant Technology has excellent resistance to surfactant leaching when applied on new or existing substrates. However, surfactants can remain on existing painted surfaces if not removed prior to coating. Existing painted surfaces must be thoroughly washed clean and allowed to dry prior to apply any finish.

SPECIFICATIONS

Duration Home Interior Latex can be used directly over existing coatings, bare drywall, or plaster (cured with a pH of less than 9).

Block:

1 coat Loxon Acrylic Block Surfer
2 coats of Duration Home Interior Latex

Drywall:

Self-prime using 2 coats of Duration Home Interior Latex

or

1 coat Premium Wall & Wood Primer
2 coats Duration Home Interior Latex

Masonry:

1 coat Loxon Concrete & Masonry Primer
2 coats Duration Home Interior Latex

Plaster:

Self-prime using 2 coats of Duration Home Interior Latex

or

1 coat Loxon Concrete & Masonry Primer
2 coats Duration Home Interior Latex

Wood:

1 coat Premium Wall & Wood Primer
2 coats Duration Home Interior Latex

If the wood has bleeding (such as tannin or knot-holes), prime with Multi-Purpose Primer.

Other primers may be appropriate.

When repainting involves a drastic color change, or coating over heavily stained areas, a coat of primer will improve the hiding performance of the topcoat color.

Duration Home[®]

Interior Latex Flat

SURFACE PREPARATION

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer-sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Caulking:

Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.

Drywall:

Fill cracks and holes with patching paste-spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block:

All new surfaces must be cured according to the supplier's recommendations – usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.

SURFACE PREPARATION

Mildew:

Clean mildew from the Surface: Mildew is a fungus that looks like dirt but won't wash off. Mildew must be removed before painting, or it will grow through any new coat of paint. To remove mildew or suspected mildew, scrub surface before painting with a commercial mildew remover following manufacturer's safety instructions.

Plaster:

Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of clean water. Repeat until the surface is hard, rinse with clean water and allow to dry.

Wood:

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

CAUTIONS

For interior use only.
Protect from freezing.
Non-Photochemically reactive.

Before using, carefully read **CAUTIONS on label**.

Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (**NIOSH** approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

HOTW 11/10/2025 A95W02351 02 08
FRC,SP

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm clean water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.